



Hyva

## Parts Catalogue 2022

Taylor Engineering & Fabrications Ltd

Unit D, St Clements Road, Nechells, Birmingham, B7 5AF

Tel: 0121 326 9035 – option 1 for refuse parts

Precision Engineering and Coded Welding

Suppliers of parts for refuse vehicles and bin lifting equipment

[www.tayloengineeringltd.co.uk](http://www.tayloengineeringltd.co.uk)



Tel: 0121 326 9035 – option 1

## Quick reference parts lists

OEM P/N	Description	Taylor Engineering P/N
N/A	Proxy switch PNP N/C Hyva jack leg	TEL2046
N/A	Black booted push button complete Hyva	TEL2278
N/A	Hyva proxy M18 45mm NPN NC	TEL2459
N/A	Hyva skip net later mighty mesh	TEM1072/4MM
N/A	Hyva mighty mesh net Gladiator/Transcover/Autocover/Ed	TEM1072/MM
N/A	Hyva upper arm left hand	TEM1215
N/A	Hyva upper arm right hand	TEM1216
N/A	Lower arm Hyva fixed system both sides Hook Loader	TEM1582/1
N/A	Tension spring only Hyva Hook Loader	TEM1869/2
N/A	Screw c/sink Hyva ext skip arm wear pads	TEM1958/1
N/A	Use TEM1519/1	TEM6116/2
N/A	Spring for Hyva roller also same spring in TEM6054	TES4040
N/A	Seal/wiper kit Hyva skip handle bracket/ spool Veolia St Alb	TEZ9044
05160301	Bush Hyva tipping frame pin pivot	TEM6092/1
05210201	Roller large load cell Hyva roll on	TEM1492
05210401	Pin for roller load cell Hyva roll on	TEM1493
06050004	Pin tipping frame pivot Hyva Hook Loader	TEM6092
07050008	Front wear pad Upper Boom arm Hook Loader	TEM1909
0750002AA	Front wear pad Lower Boom arm Hook Loader	TEM1910
08050008	Rear wear Pad Upper Boom Arm Hook Loader	TEM1915
08050009	Rear wear Pad Lower Boom Arm Hook Loader	TEM1914
08102116	Hyva breather filter c/w cap	TEF5022
08102117	BREATHER FILTER HYVA	TEF5017
08102129	Oil level tank gauge (sight glass) 3" Hyva skip	TEV3071
08100001AA	Hook mounting pin Hyva	TEM6116/1
09030635	Hyva rear lock cylinder 3 port	TEM6149
09228168V	Proxy switch body raise/boom up/Hyva & net	TEL2363
14896991A	Main Filter Hyva Skip & Hook Loader	TEF5016
15029030	Circlip for TEM6132 Hyva	TEM6132/1
31020100	Valve rear lock with plunger Hyva titan	TEV3035/2
30120101	HYVA DIVERTER VALVE	TEV3035
34010100	Hyva tip hook operating valve 5 port with lever	TEV3032
35010220	Arrow indicator lamp, red Hyva in cab box	TEL2190
35010224	Arrow Indicator Lamp Led Green in cab box	TEL2190/1
36000140	Circlip tipping pin retainer Hyva Hook Loader	TEM6092/2
36010120	Circlip link arm BRG DE1002054 Hyva	TEM1519/1
37200002	1/8 BSP Straight grease nipple misc goes with TEM6167/1	TEX5018
52340810	Hyva stabilizer coverES2	TEM6130
520203824	PTO AIR SWITCH Hyva Skip Wagon in Cab	TEV3047
521700615	Hyva in out cylinder adjustable	TEM6137
522602500	Roller small load cell Hyva roll on	TEM1491
522603800	Guard Hyva rear lamp early type Hook Loader	TEM1060



<b>522619700</b>	Guard Hyva rear lamp later type Titan Hook Loader	TEM1060/1
<b>523316610</b>	Hyva skip wide angle mirror	TEM6117
<b>523316650</b>	Hyva skip wide angle mirror arm	TEM6118
<b>523317480</b>	Square insert LDPE Hyva	TEM6131
<b>523402300</b>	Arm connecting pin Hyva Auto sheet	TEM6152
<b>523402300</b>	Hyva upper arm pin autosheet	TEM1581/1
<b>523402471</b>	Cylinder pivot pin Hyva Auto sheet	TEM6151
<b>523402491</b>	Lower arm cylinder pin Hyva Auto sheet	TEM6153
<b>523402800</b>	Bar tarp Hyva net system Hook Loader	TEM6014
<b>523405500</b>	Lower Arm Easy Sheet Adjustable width system	TEM6053/1
<b>523406025</b>	Hyva ES2 wear pad 375X25X4	TEM6135
<b>523406065</b>	Hyva ES2 wear pad 375X60X4	TEM6136
<b>523406200</b>	Upper Arm Easy Sheet Adjustable width system	TEM6053
<b>523407400</b>	Telescopic external section Hyva ES2	TEM6134
<b>523407761</b>	Hyva pin 65mm	TEM6132
<b>523407788</b>	Hyva pin 92mm	TEM6132/2
<b>523407900</b>	Telescopic internal section Hyva ES2	TEM6133
<b>523410500</b>	HYVA Lower arm, sheeting system	TEM1327
<b>523410500</b>	Hyva hook autosheet lower arm	TEM6150
<b>523411000</b>	Cradle for Hyva Kwik Cova	TEM1764
<b>523411000</b>	Hyva Kwik Cova cradle NOW USE TEM1764	TEM1336
<b>523411100</b>	Stabilizer bar for Hyva Kwik Cova cradle	TEM1764/1
<b>523411200</b>	UPPER ARM, HYVA KWIK KOVA R/H	TEM1581
<b>523411201</b>	UPPER ARM, HYVA KWIK KOVA L/H	TEM1582
<b>523413100</b>	Tension Spring Hook Loader	TEM1869
<b>523413110</b>	Spring Roller Easy Sheet Adjustable width system	TEM6054
<b>523413500</b>	Hyva skip net early chain	TEM1072/1
<b>523414500</b>	Roller skip net Hyva	TEM1869/1
<b>523415400</b>	Tension Spring Skip Netting System	TES4052R/H
<b>523415401</b>	Tension Spring Skip Netting System	TES4051L/H
<b>523418200</b>	Hyva net old & new system adjustable	TEM1072
<b>523418400</b>	Hyva skip net mighty mesh (early) chain	TEM1072/2MM
<b>523442100</b>	Hyva skip net later version	TEM1072/4
<b>523620360</b>	Amber Light in cab box	TEL2190/2
<b>523622000</b>	Decal SWL Skip Wagon Various	TEM6022
<b>523628724</b>	Hyva control valve solenoid 19W	TEV3094
<b>761002315</b>	Bush T1 hoist Farid 08160000044 Hyva 761002315	TEM1691
<b>AE080083</b>	Hyva titan container roller pin	TEM6127/1
<b>AE081666</b>	Hyva titan container roller	TEM6127
<b>AE082065</b>	Boom arm slide wear pad rest Hyva AE082065 AE080065	TEM6108
<b>AE082065</b>	Hyva titan bridge wear plate	TEM6112
<b>AE090802</b>	Hyva hook asm	TEM6116/3
<b>H0000726</b>	Hyva roll on/off goose neck rest pad	TEM1360
<b>H0000758</b>	Hyva roll on/off base plate to go with TEM1360	TEM1361
<b>H0004036</b>	Hyva hook no latch special (UK)	TEM6116
<b>N0598027K</b>	Wear pad Hyva ext skip arm (sides)	TEM1958
<b>N0598048K</b>	Wear pad Hyva ext skip arm (top/bottom)	TEM1959





<b>N0609513</b>	Bracket for Ram Guard Hyva	TEM1091/1
<b>N0609522K</b>	Hyva skip arm pivot bush	TEM6121
<b>N0609524</b>	Bracket for Ram Guard Base End	TEM1091/2
<b>N0945108</b>	Hyva ram guard slider rails	TEM1092
<b>N0960752</b>	Hyva skip ram guard channel cover	TEM1091
<b>NB000372</b>	Coil Emergency Stop Valve & Dump Valve	TEV3081
<b>P1000155</b>	Container stop Hyva Skip	TEM1539
<b>P1003873</b>	Mounting Plate, rod end, new Hyva skip ram guard	TEM1753
<b>P1003874</b>	Hyva skip ram guard new type	TEM1607
<b>P1003876</b>	Bearing block base end new Hyva skip guard	TEM1754




## Filters

	TEF5016	Hyva skip & Hook Loader main filter (14896991A)
	TEF5017	Hyva Hook Loader breather filter (08102117)
	TEF5022	Hyva breather filter c/w cap (08102116)

## Switches and Electrical

	TEL2046	Proxy switch PNP N/C Hyva jack leg
	TEL2190	Arrow indicator lamp red Hyva in cab box



	TEL2190/1	Hyva arrow indicator lamp, green, in cab box
	TEL2190/2	Hyva led light, round, yellow, in cab box
	TEL2278	Black booted push button complete Hyva
	TEL2363	Proxy switch body raise/ boom up/ Hyva (09228168V) & net
	TEL2459	Hyva proxy M18 45mm NPN NC



## Mechanical







	<p>TEM1060</p>	<p>Guard Hyva rear lamp early type Hook Loader</p>
	<p>TEM1060/1</p>	<p>Guard Hyva rear lamp later type Titan Hook Loader</p>
	<p>TEM1072</p>	<p>Hyva net old system and new system adjustable</p>
	<p>TEM1072/1</p>	<p>Hyva skip net early chain</p>
	<p>TEM1072/2 MM</p>	<p>Hyva skip net mighty mesh (early) chain</p>
	<p>TEM1072/4</p>	<p>Hyva skip net later version</p>



	<p>TEM1072/4 MM</p>	<p>Hyva skip net later Mighty Mesh</p>
	<p>TEM1072/ MM</p>	<p>Hyva Mighty Mesh net Gladiator / Transcover / Autocover / Edbro</p>
	<p>TEM1091</p>	<p>Hyva skip ram guard channel cover (N0960752)</p>
	<p>TEM1091/1</p>	<p>Hyva bracket for ram guard (N0609513)</p>
	<p>TEM1091/2</p>	<p>Hyva bracket ram guard base end (N060924)</p>
	<p>TEM1092</p>	<p>Hyva ram guard slider rails (N0945108).</p>





	<p>TEM1327</p>	<p>Hyva lower arm sheeting system (5234 105 00)</p>
	<p>TEM1360</p>	<p>Hyva roll on/ off goose neck rest pad</p>
	<p>TEM1361</p>	<p>Hyva roll on/ off base plate to go with TEM1360</p>
	<p>TEM1491</p>	<p>Roller small load cell Hyva roll on</p>
	<p>TEM1492</p>	<p>Roller large load cell Hyva roll on</p>
	<p>TEM1493</p>	<p>Pin for roller load cell Hyva roll on</p>



	<p>TEM1519/1</p>	<p>Circlip link arm BRG DE1002054/ Hyva 36010120</p>
	<p>TEM1539</p>	<p>Hyva container stop skip (P1000155)</p>
	<p>TEM1581</p>	<p>Hyva Kwik Cova upper arm right hand (523411200)</p>
	<p>TEM1581/1</p>	<p>Hyva upper arm pin autosheet</p>
	<p>TEM1582</p>	<p>Hyva Kwik Cova upper arm left hand (523411201)</p>
	<p>TEM1582/1</p>	<p>Lower arm Hyva fixed system both sides Hook Loader</p>



	<p>TEM1607</p>	<p>Hyva skip ram guard new type P1003874</p>
	<p>TEM1691</p>	<p>Bush T1 hoist Farid 08160000044 (Hyva 761002315)</p>
	<p>TEM1753</p>	<p>Hyva mounting plate rod end new skip guard (P1003873)</p>
	<p>TEM1754</p>	<p>Bearing block base end new Hyva skip guard P1003876</p>
	<p>TEM1764</p>	<p>Hyva Kwik Cova cradle (523411000) Pic below</p>
		









	<p>TEM1764/1</p>	<p>Hyva Kwik Cova stabilizer bar cradle (523411100)</p>
		
	<p>TEM1869</p>	<p>Hook Loader tension spring (523413100)</p>
	<p>TEM1869/1</p>	<p>Roller skip net Hyva 523414500</p>
	<p>TEM1869/2</p>	<p>Tension spring only Hyva Hook Loader</p>
	<p>TEM1909</p>	<p>Hook Loader front wear pad upper Hyva boom arm</p>









	TEM1910	Hyva Hook Loader front wear pad lower boom arm
	TEM1914	Hyva Hook Loader rear wear pad lower boom arm
	TEM1915	Hook Loader Hyva rear wear pad upper boom arm
	TEM1958	Wear pad Hyva ext skip arm (sides) N0598027K
	Tem1958/1	Screw c/sink Hyva ext skip arm wear pads
	TEM1959	Wear pad Hyva ext skip arm (top/ bottom) N0598048K



	<p>TEM6014</p>	<p>Bar tarp Hyva net system Hook Loader (image below)</p>
		
	<p>TEM6022</p>	<p>Decal SWL skip wagon various (523622000)</p>
	<p>TEM6053</p>	<p>Upper arm adjustable width system (523406200)</p>
	<p>TEM6053/1</p>	<p>Lower arm easy sheet adjustable width system (523405500)</p>
	<p>TEM6054</p>	<p>Spring roller easy sheet adjustable width system (523413110)</p>



	TEM6092	Pin tipping frame pivot Hyva Hook Loader (06050004)
	TEM6092/1	Bush Hyva tipping frame pin pivot (05160301)
	TEM6092/2	Circlip tipping pin retainer Hyva Hook Loader (36000140)
	TEM6108	Boom arm slide wear pad rest Hyva AE082065 AE080065
	TEM6112	Hyva titan bridge wear plate AE082065
	TEM6116	Hyva hook no latch special (UK) H0004036



	<p>TEM6116/1</p>	<p>Hook mounting pin Hyva 08100001AA</p>
	<p>TEM6116/1 0</p>	<p>S/S External circlip for TEM6116 hook (55mm pin) (36010110)</p>
	<p>TEM6116/1 1</p>	<p>S/S Internal circlip for TEM6116 hook (55mm pin)</p>
	<p>TEM6116/3</p>	<p>Hyva hook asm AE090802</p>
	<p>TEM6116/3 1</p>	<p>S/S Internal circlip TEM6116/3 Hook (60mm pin) (36010120)</p>
	<p>TEM6117</p>	<p>Hyva skip wide angle mirror 523316610</p>





	TEM6118	Hyva skip wide angle mirror arm 523316650
	TEM6121	Hyva skip arm pivot bush N0609522K
	TEM6127	Hyva titan container roller AE081666
	TEM6127/1	Hyva titan container roller pin AE080083
	TEM6130	Hyva stabilizer cover ES2 52340810
	TEM6131	Square insert LDPE Hyva 523317480




	TEM6132	Hyva pin 523407761 65mm
	TEM6132/1	Circlip for TEM6132 Hyva 15029030
	TEM6132/2	Pin Hyva 523407788 92mm
	TEM6133	Telescopic internal section Hyva ES2 523407900
	TEM6134	Telescopic external section Hyva ES2 523407400
	TEM6135	Hyva ES2 wear pad 375X25X4 523406025






	TEM6136	Hyva ES2 wear pad 375X60X4 523406065
	TEM6137	Hyva in out cylinder adjustable 521700615
	TEM6149	Hyva rear lock cylinder 3 port (09030635)
	TEM6150	Hyva hook autosheet lower arm 523410500
	TEM6151	Cylinder pivot pin Hyva auto sheet 523402300
	TEM6152	Arm connecting pin Hyva autosheet 523402300



	<p>TEM6153</p>	<p>Lower arm cylinder pin Hyva autosheet 523402491</p>
---	----------------	--

## Hyva Springs



	<p>TES4040</p>	<p>Spring for Hyva roller also same spring in TEM6054</p>
	<p>TES4051 L/H</p>	<p>Tension spring skip netting system (523415401)</p>
	<p>TES4052 R/H</p>	<p>Tension spring skip netting system (523415400)</p>



# Hyva Valves

	TEV3032	Hyva tip hook operating valve 5 port with lever 34010100
	TEV3035	Hyva diverter valve (30120101)
	TEV3035/2	Valve rear lock with plunger Hyva titan (31020100)
	TEV3047	Hyva PTO air switch skip wagon in cab (520203824)
	TEV3071	Oil level tank gauge (sight glass) 3" Hyva skip 08102129
	TEV3081	Coil Emergency Stop Valve & Dump Valve (NB000372)



	TEV3094	Hyva control valve solenoid 19w 523628724
	TEX5018	1/8 BSP Straight grease nipple misc goes with TEM6167/1

