



Hyva

Parts Catalogue 2026

Taylor Engineering & Fabrications Ltd

Unit D, St Clements Road, Nechells, Birmingham, B7 5AF

Tel: 0121 326 9035 – option 1 for refuse parts

Precision Engineering and Coded Welding

**Suppliers of parts for refuse vehicles and bin lifting
equipment**

www.tayloengineeringltd.co.uk



Tel: 0121 326 9035 – option 1

Quick reference parts lists

OEM P/N	Description	Taylor Engineering P/N
N/A	Proxy switch PNP N/C Hyva jack leg	TEL2046
N/A	Black booted push button complete Hyva	TEL2278
N/A	Hyva proxy M18 45mm NPN NC	TEL2459
N/A	IMO inductive proxy switch M18 no npn body lock	TEL2510
N/A	Hyva skip net later mighty mesh	TEM1072/4MM
N/A	Hyva mighty mesh net Gladiator/Transcover/Autocover/Ed	TEM1072/MM
N/A	Hyva upper arm left hand	TEM1215
N/A	Hyva upper arm right hand	TEM1216
N/A	Lower arm Hyva fixed system both sides Hook Loader	TEM1582/1
N/A	Tension spring only Hyva Hook Loader	TEM1869/2
N/A	Screw c/sink Hyva ext skip arm wear pads	TEM1958/1
N/A	Hyva cradle for Hook Loader 2656 3mm thickness	TEM6309
N/A	Hyva skip mounting axle pin for lower extending arm	TEM6312
N/A	Hyva rubber bump stop/crossmember buffer	TEM7093
N/A	Spring for Hyva roller also same spring in TEM6054	TES4040
N/A	Seal/wiper kit Hyva skip handle bracket/ spool Veolia St Alb	TEZ9044
05160301	Bush Hyva tipping frame pin pivot	TEM6092/1
05210201	Roller large load cell Hyva roll on	TEM1492
05210401	Pin for roller load cell Hyva roll on	TEM1493
06050004	Pin tipping frame pivot Hyva Hook Loader	TEM6092
07050008	Front wear pad Upper Boom arm Hook Loader	TEM1909
0750002AA	Front wear pad Lower Boom arm Hook Loader	TEM1910
08050008	Rear wear Pad Upper Boom Arm Hook Loader	TEM1915
08050009	Rear wear Pad Lower Boom Arm Hook Loader	TEM1914
08102116	Hyva breather filter c/w cap	TEF5022
08102117	BREATHER FILTER HYVA	TEF5017
08102129	Oil level tank gauge (sight glass) 3" Hyva skip	TEV3071
08100001AA	Hook mounting pin Hyva	TEM6116/1
09030635	Hyva rear lock cylinder 3 port	TEM6149
09228168V	Proxy switch body raise/boom up/Hyva & net	TEL2363
14896991A	Main Filter Hyva Skip & Hook Loader	TEF5016
15029030	Circlip for TEM6132 Hyva	TEM6132/1
31020100	Valve rear lock with plunger Hyva titan	TEV3035/2
31020101	HYVA DIVERTER VALVE	TEV3035
34010100	Hyva tip hook operating valve 5 port with lever	TEV3032
35010220	Arrow indicator lamp, red Hyva in cab box	TEL2190
35010224	Arrow Indicator Lamp Led Green in cab box	TEL2190/1
36000140	Circlip tipping pin retainer Hyva Hook Loader	TEM6092/2
36010120	Circlip link arm BRG DE1002054 Hyva	TEM1519/1
36207560	Hyva Hook Loader bush/flange bearing for rear roller	TEM6311
37200002	1/8 BSP Straight grease nipple misc goes with TEM6167/1	TEX5018
52340810	Hyva stabilizer coverES2	TEM6130
350103105	Jack leg sensor/pressure switch	TEL2481




520200310	Hold to run double switch	TEL2470/1
520203824	PTO AIR SWITCH Hyva Skip Wagon in Cab	TEV3047
521700615	Hyva in out cylinder adjustable	TEM6137
522602500	Roller small load cell Hyva roll on	TEM1491
522603800	Guard Hyva rear lamp early type Hook Loader	TEM1060
522619700	Guard Hyva rear lamp later type Titan Hook Loader	TEM1060/1
523316610	Hyva skip wide angle mirror	TEM6117
523316650	Hyva skip wide angle mirror arm	TEM6118
523317480	Square insert LDPE Hyva	TEM6131
523402300	Arm connecting pin Hyva Auto sheet	TEM6152
523402300	Hyva upper arm pin autosheet	TEM1581/1
523402471	Cylinder pivot pin Hyva Auto sheet	TEM6151
523402491	Lower arm cylinder pin Hyva Auto sheet	TEM6153
523402800	Bar tarp Hyva net system Hook Loader	TEM6014
523405500	Lower Arm Easy Sheet Adjustable width system	TEM6053/1
523405500	Hyva Lower arm easysheet/autosheet	TEM6160
523406025	Hyva ES2 wear pad 375X25X4	TEM6135
523406065	Hyva ES2 wear pad 375X60X4	TEM6136
523406200	Upper Arm Easy Sheet Adjustable width system	TEM6053
523407400	Telescopic external section Hyva ES2	TEM6134
523407761	Hyva pin 65mm	TEM6132
523407788	Hyva pin 92mm	TEM6132/2
523407900	Telescopic internal section Hyva ES2	TEM6133
523410500	HYVA Lower arm, sheeting system	TEM1327
523410500	Hyva hook autosheet lower arm	TEM6150
523411000	Cradle for Hyva Kwik Cova	TEM1764
523411000	Hyva Kwik Cova cradle NOW USE TEM1764	TEM1336
523411100	Stabilizer bar for Hyva Kwik Cova cradle	TEM1764/1
523411200	UPPER ARM, HYVA KWIK KOVA R/H	TEM1581
523411201	UPPER ARM, HYVA KWIK KOVA L/H	TEM1582
523413100	Tension Spring Hook Loader	TEM1869
523413110	Spring Roller Easy Sheet Adjustable width system	TEM6054
523413500	Hyva skip net early chain	TEM1072/1
523414500	Roller skip net Hyva	TEM1869/1
523415400	Tension Spring Skip Netting System	TES4052R/H
523415401	Tension Spring Skip Netting System	TES4051L/H
523418200	Hyva net old & new system adjustable	TEM1072
523418400	Hyva skip net mighty mesh (early) chain	TEM1072/2MM
523442100	Hyva skip net later version	TEM1072/4
523620360	Amber Light in cab box	TEL2190/2
523622000	Decal SWL Skip Wagon Various	TEM6022
523628724	Hyva control valve solenoid 19W	TEV3094
761002315	Bush T1 hoist Farid 08160000044 Hyva 761002315	TEM1691
AE080083	Hyva titan container roller pin	TEM6127/1
AE081666	Hyva titan container roller	TEM6127
AE082065	Boom arm slide wear pad rest Hyva AE082065 AE080065	TEM6108
AE082065	Hyva titan bridge wear plate	TEM6112
AE090134	Hyva Hook Loader rear roller chem spacer	TEM6310



AE090789	Hyva pin for TEM6116 60mm pin	TEM6116/4
AE090802	Hyva hook asm	TEM6116/3
H0000726	Hyva roll on/off goose neck rest pad	TEM1360
H0000758	Hyva roll on/off base plate to go with TEM1360	TEM1361
H0003928	Hyva weld claw UK locking left hand	TEM6190/LH
H0003931	Hyva weld claw UK locking right hand	TEM6190/RH
H0004036	Hyva hook no latch special (UK)	TEM6116
N0220035	Hyva rocker hella switch	TEL2476
N0598026K	Hyva skip arm lower slide pad (1477/1 bolt)	TEM6175
N0598027K	Wear pad Hyva ext skip arm (sides)	TEM1958
N0598048K	Wear pad Hyva ext skip arm (top/bottom)	TEM1959
N0609513	Bracket for Ram Guard Hyva	TEM1091/1
N0609522K	Hyva skip arm pivot bush	TEM6121
N0609524	Bracket for Ram Guard Base End	TEM1091/2
N0945108	Hyva ram guard slider rails	TEM1092
N0960752	Hyva skip ram guard channel cover	TEM1091
NB000372	Coil Emergency Stop Valve & Dump Valve	TEV3081
P1000155	Container stop Hyva Skip	TEM1539
P1003856	Hyva wear pad circular XL-TA synthetic	TEM6320
P1003873	Mounting Plate, rod end, new Hyva skip ram guard	TEM1753
P1003874	Hyva skip ram guard new type	TEM1607
P1003876	Bearing block base end new Hyva skip guard	TEM1754
P1260279	Hyva air cylinder tip hook skip loader (later)	TEV3100

Filters


	TEF5016	Hyva skip & Hook Loader main filter (14896991A)
	TEF5017	Hyva Hook Loader breather filter (08102117)
	TEF5022	Hyva breather filter c/w cap (08102116)



Switches and Electrical

	TEL2046	Proxy switch PNP N/C jack leg
	TEL2190	Arrow indicator lamp (red) in cab box
	TEL2190/1	Arrow indicator lamp (green) in cab box
	TEL2190/2	LED light, round (yellow) in cab box
	TEL2242	Proxy Skip,r/lock various, c/w loom; NC NPN (H0003573)
	TEL2278	Black booted push button complete



	TEL2363	Proxy switch body raise/ boom up (09228168V)
	TEL2459	Proxy M18 45mm NPN NC
	TEL2470	Hold to run switch (520200300)
	TEL2470/1	“Hold To Run” double switch (520200310)
	TEL2476	Rocker hella switch (N0220035)
	TEL2481	Jack leg sensor/pressure switch (350103105)



	TEL2510	IMO inductive proxy switch M18 NO NPN body lock
---	---------	---

Mechanical

	TEM1060	Guard rear lamp early type Hook Loader
	TEM1060/1	Guard rear lamp later type Titan Hook Loader
	TEM1072	Net old system and new system (adjustable)
	TEM1072/1	Skip net early chain



	TEM1072/2 MM	Skip net mighty mesh (early) chain
	TEM1072/2 GM	Skip net premium (early) chain
	TEM1072/4 GM	Skip net premium (later) mech/hyd
	TEM1072/4	Skip net (later version)
	TEM1072/4 MM	Skip net (later version) Mighty Mesh
	TEM1072/ MM	Mighty Mesh net Gladiator/Transcover/Autocover/Edbro



	TEM1091	Skip ram guard channel cover (N0960752)
	TEM1091/1	Bracket for ram guard (N0609513)
	TEM1091/2	Bracket ram guard base end (N060924)
	TEM1092	Ram guard slider rails (N0945108).
	TEM1215	Upper arm left hand
	TEM1216	Upper arm right hand




	TEM1315	Skip netting system top tube (523415200)
	TEM1327	Lower arm sheeting system (5234 105 00)
	TEM1360	Roll on/off goose neck rest pad
	TEM1361	Roll on/off base plate to go with TEM1360
	TEM1491	Roller small load cell (roll on)
	TEM1492	Roller large load cell (roll on)




	TEM1493	Pin for roller load cell (roll on)
	TEM1519/1	Circlip link arm bearing (DE1002054/36010120)
	TEM1539	Container stop skip (P1000155)
	TEM1581	Hyva Kwik Cova upper arm right hand (523411200)
	TEM1581/1	Hyva upper arm pin autosheet
	TEM1582	Hyva Kwik Cova upper arm left hand (523411201)



	TEM1582/1	Lower arm fixed system both sides Hook Loader
	TEM1607	Skip ram guard new type (P1003874)
	TEM1691	Bush T1 hoist Farid (08160000044) (761002315)
	TEM1753	Mounting plate rod end new skip guard (P1003873)
	TEM1754	Bearing block base end (skip guard) (P1003876)
	TEM1764	Hyva Kwik Cova cradle (523411000) Pic below




		
	TEM1764/1	Kwik Cova stabilizer bar cradle (523411100)
		
	TEM1869	Hook Loader tension spring (523413100)
	TEM1869/1	Roller skip net (523414500)
	TEM1869/2	Tension spring only Hook Loader




	TEM1909	Hook Loader front wear pad (upper boom arm)
	TEM1910	Hook Loader front wear pad (lower boom arm)
	TEM1914	Hook Loader rear wear pad (lower boom arm)
	TEM1915	Hook Loader rear wear pad (upper boom arm)
	TEM1958	Wear pad ext skip arm (sides) (N0598027K)
	Tem1958/1	Screw c/sink ext skip arm wear pads




	TEM1958/2	Retaining plate large skip (N0955826)
	TEM1959	Wear pad ext skip arm (top/ bottom) (N0598048K)
	TEM1959/1	Retaining plate small skip (N0955823)
	TEM6014	Bar tarp net system Hook Loader (image below)
		
	TEM6022	Decal SWL skip wagon various (523622000)



	TEM6053	Upper arm adjustable width system (523406200)
	TEM6053/1	Lower arm easy sheet adjustable width system (523405500)
	TEM6054	Spring roller easy sheet adjustable width system (523413110)
	TEM6092	Pin tipping frame pivot Hook Loader (06050004)
	TEM6092/1	Bush tipping frame pin pivot (05160301)
	TEM6092/2	Circlip tipping pin retainer Hook Loader (36000140)



	TEM6108	Boom arm slide wear pad rest (AE082065/AE080065)
	TEM6112	Titan bridge wear plate (AE082065)
	TEM6116	Cranked hook 60mm pin (AE090802)
	TEM6116/1	Hook mounting pin (08100001AA)
	TEM6116/1 0	S/S External circlip for TEM6116 hook (55mm pin) (36010110)
	TEM6116/1 1	S/S Internal circlip for TEM6116 hook (55mm pin)





	TEM6116/3	Hyva Hook T-shaped 55mm pin Asm H00004036
	TEM6116/3 1	S/S Internal circlip TEM6116/3 Hook (60mm pin) (36010120)
	TEM6116/4	Pin for TEM6116 60mm pin (AE090789)
	TEM6117	Skip wide angle mirror (523316610)
	TEM6118	Skip wide angle mirror arm (523316650)
	TEM6121	Skip arm pivot bush (N0609522K)



	TEM6127	Titan container roller (AE081666)
	TEM6127/1	Titan container roller pin (AE080083)
	TEM6130	Stabilizer cover ES2 (52340810)
	TEM6131	Square insert LDPE (523317480)
	TEM6132	Pin 65mm (523407761)
	TEM6132/1	Circlip for TEM6132 (15029030)



	TEM6132/2	Pin 92mm (523407788)
	TEM6133	Telescopic internal section ES2 (523407900)
	TEM6134	Telescopic external section ES2 (523407400)
	TEM6135	Wear pad ES2 (375X25X4) (523406025)
	TEM6136	Wear pad ES2 (375X60X4/523406065)
	TEM6137	In/out cylinder (adjustable) (521700615)



	TEM6149	Rear lock cylinder 3 port (09030635)
	TEM6150	Hook autosheet lower arm (523410500)
	TEM6151	Cylinder pivot pin auto sheet (523402300)
	TEM6152	Arm connecting pin autosheet (523402300)
	TEM6153	Lower arm cylinder pin autosheet (523402491)
	TEM6160	Skip lower arm easysheet/autosheet (523405500)



	TEM6175	Skip arm lower slide pad (1477/1 bolt) (N0598026K)
	TEM6185/L H	N/S skip arm (early - chain driven)
	TEM6185/R H	O/S skip arm (early - chain driven)
	TEM6190/L H	Weld claw UK locking left hand (H0003928)
	TEM6190/R H	Weld claw UK locking right hand (H0003931)
	TEM6309	Cradle for Hook Loader 2656 (3mm thickness)



	TEM6310	Hook Loader rear roller chem spacer (AE090134)
	TEM6311	Hook Loader bush/flange bearing for rear roller (36207560)
	TEM6312	Skip mounting axle pin for lower extending arm
	TEM6320	Wear pad circular XL-TA synthetic (P1003856)
	TEM7090	Skip hinge (large) (250mm long)
	TEM7092/1	Strap hinge (160 x 40 x 6 approx)



	TEM7092/2	Hinge (Gudgeon) Pin (95 x 25 x 25 approx)
	TEM7093	Rubber bump stop/crossmember buffer

Springs

	TES4040	Spring for Hyva roller (Same spring in TEM6054)
	TES4051 L/H	Tension spring skip netting system (523415401)
	TES4052 R/H	Tension spring skip netting system (523415400)



Valves

	TEV3032	Tip hook operating valve 5 port with lever (34010100)
	TEV3035	Diverter valve (31020101)
	TEV3035/2	Valve rear lock with plunger titan (31020100)
	TEV3047	PTO air switch skip wagon in cab (520203824)
	TEV3071	Oil level tank gauge (sight glass) 3" Hyva skip (08102129)
	TEV3081	Coil emergency stop valve & dump valve (NB000372)



	TEV3094	Control valve solenoid 19w (523628724)
	TEV3100	Air cylinder tip hook skip loader (later) (P1260279)

Specials

	TEX5018	1/8 BSP Straight grease nipple misc goes with TEM6167/1
	TEZ9044	Seal/wiper kit (skip handle bracket/spool)
	TEZ9076	Pull over cylinder (521700424)

