Hyva

Parts Catalogue 2026

Taylor Engineering & Fabrications Ltd

Unit D, St Clements Road, Nechells, Birmingham, B7 5AF

Tel: 0121 326 9035 – option 1 for refuse parts

Precision Engineering and Coded Welding

Suppliers of parts for refuse vehicles and bin lifting equipment

www.taylorengineeringltd.co.uk

Quick reference parts lists

OEM P/N	Description	Taylor Engineering P/N
N/A	Proxy switch PNP N/C Hyva jack leg	TEL2046
N/A	Black booted push button complete Hyva	TEL2278
N/A	Hyva proxy M18 45mm NPN NC	TEL2459
N/A	IMO inductive proxy switch M18 no npn body lock	TEL2510
N/A	Hyva skip net later mighty mesh	TEM1072/4MM
N/A	Hyva mighty mesh net Gladiator/Transcover/Autocover/Ed	TEM1072/MM
N/A	Hyva upper arm left hand	TEM1215
N/A	Hyva upper arm right hand	TEM1216
N/A	Lower arm Hyva fixed system both sides Hook Loader	TEM1582/1
N/A	Tension spring only Hyva Hook Loader	TEM1869/2
N/A	Screw c/sink Hyva ext skip arm wear pads	TEM1958/1
N/A	Hyva cradle for Hook Loader 2656 3mm thickness	TEM6309
N/A	Hyva skip mounting axle pin for lower extending arm	TEM6312
N/A	Hyva rubber bump stop/crossmember buffer	TEM7093
N/A	Spring for Hyva roller also same spring in TEM6054	TES4040
N/A	Seal/wiper kit Hyva skip handle bracket/ spool Veolia St Alb	TEZ9044
05160301	Bush Hyva tipping frame pin pivot	TEM6092/1
05210201	Roller large load cell Hyva roll on	TEM1492
05210401	Pin for roller load cell Hyva roll on	TEM1493
06050004	Pin tipping frame pivot Hyva Hook Loader	TEM6092
07050008	Front wear pad Upper Boom arm Hook Loader	TEM1909
0750002AA	Front wear pad Lower Boom arm Hook Loader	TEM1910
08050008	Rear wear Pad Upper Boom Arm Hook Loader	TEM1915
08050009	Rear wear Pad Lower Boom Arm Hook Loader	TEM1914
08102116	Hyva breather filter c/w cap	TEF5022
08102117	BREATHER FILTER HYVA	TEF5017
08102129	Oil level tank gauge (sight glass) 3” Hyva skip	TEV3071
08100001AA	Hook mounting pin Hyva	TEM6116/1
09030635	Hyva rear lock cylinder 3 port	TEM6149
09228168V	Proxy switch body raise/boom up/Hyva & net	TEL2363
14896991A	Main Filter Hyva Skip & Hook Loader	TEF5016
15029030	Circlip for TEM6132 Hyva	TEM6132/1
31020100	Valve rear lock with plunger Hyva titan	TEV3035/2
31020101	HYVA DIVERTER VALVE	TEV3035
34010100	Hyva tip hook operating valve 5 port with lever	TEV3032
35010220	Arrow indicator lamp, red Hyva in cab box	TEL2190
35010224	Arrow Indicator Lamp Led Green in cab box	TEL2190/1
36000140	Circlip tipping pin retainer Hyva Hook Loader	TEM6092/2
36010120	Circlip link arm BRG DE1002054 Hyva	TEM1519/1
36207560	Hyva Hook Loader bush/flange bearing for rear roller	TEM6311
37200002	1/8 BSP Straight grease nipple misc goes with TEM6167/1	TEX5018
52340810	Hyva stabilizer coverES2	TEM6130
350103105	Jack leg sensor/pressure switch	TEL2481

520200310	Hold to run double switch	TEL2470/1
520203824	PTO AIR SWITCH Hyva Skip Wagon in Cab	TEV3047
521700615	Hyva in out cylinder adjustable	TEM6137
522602500	Roller small load cell Hyva roll on	TEM1491
522603800	Guard Hyva rear lamp early type Hook Loader	TEM1060
522619700	Guard Hyva rear lamp later type Titan Hook Loader	TEM1060/1
523316610	Hyva skip wide angle mirror	TEM6117
523316650	Hyva skip wide angle mirror arm	TEM6118
523317480	Square insert LDPE Hyva	TEM6131
523402300	Arm connecting pin Hyva Auto sheet	TEM6152
523402300	Hyva upper arm pin autosheet	TEM1581/1
523402471	Cylinder pivot pin Hyva Auto sheet	TEM6151
523402491	Lower arm cylinder pin Hyva Auto sheet	TEM6153
523402800	Bar tarp Hyva net system Hook Loader	TEM6014
523405500	Lower Arm Easy Sheet Adjustable width system	TEM6053/1
523405500	Hyva Lower arm easysheet/autosheet	TEM6160
523406025	Hyva ES2 wear pad 375X25X4	TEM6135
523406065	Hyva ES2 wear pad 375X60X4	TEM6136
523406200	Upper Arm Easy Sheet Adjustable width system	TEM6053
523407400	Telescopic external section Hyva ES2	TEM6134
523407761	Hyva pin 65mm	TEM6132
523407788	Hyva pin 92mm	TEM6132/2
523407900	Telescopic internal section Hyva ES2	TEM6133
523410500	HYVA Lower arm, sheeting system	TEM1327
523410500	Hyva hook autosheet lower arm	TEM6150
523411000	Cradle for Hyva Kwik Cova	TEM1764
523411000	Hyva Kwik Cova cradle NOW USE TEM1764	TEM1336
523411100	Stabilizer bar for Hyva Kwik Cova cradle	TEM1764/1
523411200	UPPER ARM, HYVA KWIK KOVA R/H	TEM1581
523411201	UPPER ARM, HYVA KWIK KOVA L/H	TEM1582
523413100	Tension Spring Hook Loader	TEM1869
523413110	Spring Roller Easy Sheet Adjustable width system	TEM6054
523413500	Hyva skip net early chain	TEM1072/1
523414500	Roller skip net Hyva	TEM1869/1
523415400	Tension Spring Skip Netting System	TES4052R/H
523415401	Tension Spring Skip Netting System	TES4051L/H
523418200	Hyva net old & new system adjustable	TEM1072
523418400	Hyva skip net mighty mesh (early) chain	TEM1072/2MM
523442100	Hyva skip net later version	TEM1072/4
523620360	Amber Light in cab box	TEL2190/2
523622000	Decal SWL Skip Wagon Various	TEM6022
523628724	Hyva control valve solenoid 19W	TEV3094
761002315	Bush T1 hoist Farid 08160000044 Hyva 761002315	TEM1691
AE080083	Hyva titan container roller pin	TEM6127/1
AE081666	Hyva titan container roller	TEM6127
AE082065	Boom arm slide wear pad rest Hyva AE082065 AE080065	TEM6108
AE082065	Hyva titan bridge wear plate	TEM6112
AE090134	Hyva Hook Loader rear roller chem spacer	TEM6310

AE090789	Hyva pin for TEM6116 60mm pin	TEM6116/4
AE090802	Hyva hook asm	TEM6116/3
H0000726	Hyva roll on/off goose neck rest pad	TEM1360
H0000758	Hyva roll on/off base plate to go with TEM1360	TEM1361
H0003928	Hyva weld claw UK locking left hand	TEM6190/LH
H0003931	Hyva weld claw UK locking right hand	TEM6190/RH
H0004036	Hyva hook no latch special (UK)	TEM6116
N0220035	Hyva rocker hella switch	TEL2476
N0598026K	Hyva skip arm lower slide pad (1477/1 bolt)	TEM6175
N0598027K	Wear pad Hyva ext skip arm (sides)	TEM1958
N0598048K	Wear pad Hyva ext skip arm (top/bottom)	TEM1959
N0609513	Bracket for Ram Guard Hyva	TEM1091/1
N0609522K	Hyva skip arm pivot bush	TEM6121
N0609524	Bracket for Ram Guard Base End	TEM1091/2
N0945108	Hyva ram guard slider rails	TEM1092
N0960752	Hyva skip ram guard channel cover	TEM1091
NB000372	Coil Emergency Stop Valve & Dump Valve	TEV3081
P1000155	Container stop Hyva Skip	TEM1539
P1003856	Hyva wear pad circular XL-TA synthetic	TEM6320
P1003873	Mounting Plate, rod end, new Hyva skip ram guard	TEM1753
P1003874	Hyva skip ram guard new type	TEM1607
P1003876	Bearing block base end new Hyva skip guard	TEM1754
P1260279	Hyva air cylinder tip hook skip loader (later)	TEV3100

Filters

	TEF5016	Main Hydraulic Filter – Hyva Skip & Hook Loader (14896991A)
	TEF5017	Breather Filter – Hyva Skip & Hook Loader (08102117)

	TEF5022	Breather Filter with Cap – Hyva Skip & Hook Loader (08102116)

Switches & Electrical

	TEL2046	IFM IGC236 Inductive sensor, M18 body, M12 connector, PNP Normally closed, 8mm sensing range
	TEL2190	Red Arrow Indicator Lamp – In-Cab Control Box
	TEL2190/1	Green Arrow Indicator Lamp – In-Cab Control Box
	TEL2190/2	Yellow Round LED Light – In-Cab Control Box
	TEL2242	IFM IG6571, Hyva hookloader proxy switch with 10mtr cable, 18mm diameter, 5mm sensing range (H0003573)

	TEL2278	Black Booted Push Button – Complete
	TEL2363	Hyva 09228168V, IFM Inductive sensor IG5557, M18 body with M12 connector, NPN N/C (09228168V)
	TEL2459	Hyva sensor, IFM IGS254, M18 body with M12 connector, 45mm long, NPN N/C
	TEL2470	Hold-to-Run Switch (520200300)
	TEL2470/1	“Hold-to-Run” Double Switch (520200310)
	TEL2476	Hella Rocker Switch (N0220035)

	TEL2481	Jack Leg Sensor/Pressure Switch (350103105)
	TEL2510	IMO inductive proxy switch M18 NO NPN body lock

Mechanical

	TEM1060	Rear Lamp Guard – Early Type Hook Loader
	TEM1060/1	Rear Lamp Guard – Later Type Titan Hook Loader
	TEM1072/2 MM	Hyva Type 2 Skip Mighty Mesh Net – Old Type, Chain Driven

	TEM1072/2 S	Hyva Type 2 Skip Standard Mesh
	TEM1072/4 MM	Hyva Type 3 Skip Mighty Mesh Net
	TEM1072/4 S	Hyva Type 3 Skip Standard Mesh
	TEM1072/3	Hyva/Edbro Hook Loader Standard Mesh
	TEM1072/1 MM	Hyva/Edbro/Transcover Hook Loader Mighty Mesh
	TEM1091	Skip Ram Guard Channel Cover – Old Type (N0960752)

	TEM1091/1	Ram Guard Bracket (N0609513)
	TEM1091/2	Ram Guard Base End Bracket (N060924)
	TEM1092	Ram Guard Slider Rails (N0945108)
	TEM1360	Roll-On/Off Gooseneck Rest Pad
	TEM1361	Roll-On/Off Base Plate – To Suit TEM1360
	TEM1491	Small Load Cell Roller – Roll-On/Off

	TEM1492	Large Load Cell Roller – Roll-On/Off
	TEM1493	Load Cell Roller Pin – Roll-On/Off
	TEM1519/1	Link Arm Bearing Circlip (36010120)
	TEM1539	Skip Container Stop (P1000155)
	TEM1581	Hyva Kwik Cova Upper Arm – Right Hand (523411200)
	TEM1581/1	Hyva Autosheet Upper Arm Pin

	TEM1582	Hyva Kwik Cova Upper Arm – Left Hand (523411201)
	TEM1582/1	Hook Loader Lower Arm – Fixed System, Both Sides
	TEM1607	Skip Ram Guard – New Type (P1003874)
	TEM1691	Farid T1 Hoist Bush (08160000044) (761002315)
	TEM1753	New Type Skip Ram Guard Rod End Mounting Plate (P1003873)
	TEM1754	Skip Ram Guard Base End Bearing Block (P1003876)

	TEM1764	Hyva Kwik Cova Hook Loader Cradle – New Type, 3mm Thick (523411000)
	TEM1764/1	Hyva Kwik Cova Stabiliser Bar Cradle (523411100)
	TEM1869	Hook Loader Tension Spring (523413100)
	TEM1869/1	Skip Net Roller (523414500)
	TEM1869/2	Hook Loader Tension Spring – Spring Only
	TEM1909	Hook Loader Front Wear Pad – Upper Boom Arm

	TEM1910	Hook Loader Front Wear Pad – Lower Boom Arm
	TEM1914	Hook Loader Rear Wear Pad – Lower Boom Arm
	TEM1915	Hook Loader Rear Wear Pad – Upper Boom Arm
	TEM1958	Skip Arm Side Wear Pad (N0598027K)
	Tem1958/1	Countersunk Screw – Skip Arm Wear Pads
	TEM1958/2	Large Skip Retaining Plate (N0955826)

	TEM1959	Skip Arm Top/Bottom Wear Pad (N0598048K)
	TEM1959/1	Small Skip Retaining Plate (N0955823)
	TEM6014	Hook Loader Tarp Net System Bar
	TEM6022	Skip Wagon SWL Decal (523622000)
	TEM6053	Adjustable Width System Upper Arm (523406200)
	TEM6053/1	Adjustable Width Easy Sheet Lower Arm (523405500)

	TEM6054	Adjustable Width Easy Sheet Spring Roller (523413110)
	TEM6092	Hook Loader Tipping Frame Pivot Pin (06050004)
	TEM6092/1	Hook Loader Tipping Frame Pivot Pin Bush (05160301)
	TEM6092/2	Hook Loader Tipping Pin Retaining Circlip (36000140)
	TEM6108	Boom Arm Slide Wear Pad Rest (AE082065/AE080065)
	TEM6112	Titan Bridge Wear Plate (AE082065)

	TEM6116	Cranked Hook (60mm pin) (AE090802)
	TEM6116/1	Hook Mounting Pin (08100001AA)
	TEM6116/10	Stainless Steel External Circlip – TEM6116 Hook, 55mm Pin (36010110)
	TEM6116/11	Stainless Steel Internal Circlip – TEM6116 Hook, 55mm Pin
	TEM6116/3	Hyva T-Shaped Hook (55mm Pin) (H00004036)
	TEM6116/31	Stainless Steel Internal Circlip – TEM6116/3 Hook, 60mm Pin (36010120)

	TEM6116/4	TEM6116 Hook Pin – 60mm (AE090789)
	TEM6117	Skip Wide-Angle Mirror (523316610)
	TEM6118	Skip Wide-Angle Mirror Arm (523316650)
	TEM6121	Skip Arm Pivot Bush (N0609522K)
	TEM6127	Titan Container Roller (AE081666)
	TEM6127/1	Titan Container Roller Pin (AE080083)

	TEM6130	ES2 Stabiliser Cover (52340810)
	TEM6131	Square LDPE Insert (523317480)
	TEM6132	65mm Pin (523407761)
	TEM6132/1	TEM6132 Circlip (15029030)
	TEM6132/2	92mm Pin (523407788)
	TEM6133	ES2 Telescopic Internal Section (523407900)

	TEM6134	ES2 Telescopic External Section (523407400)
	TEM6135	ES2 Wear Pad (375X25X4) (523406025)
	TEM6136	ES2 Wear Pad (375X60X4/523406065)
	TEM6137	Adjustable In/Out Cylinder (521700615)
	TEM6149	3-Port Rear Lock Cylinder (09030635)
	TEM6150	Hook Loader Autosheet Lower Arm (523410500)

	TEM6151	Autosheet Cylinder Pivot Pin (523402300)
	TEM6152	Autosheet Arm Connecting Pin (523402300)
	TEM6153	Autosheet Lower Arm Cylinder Pin (523402491)
	TEM6160	Skip Lower Arm – Easy Sheet / Autosheet (523405500)
	TEM6175	Skip Lower Arm Slide Pad (1477/1 bolt) (N0598026K)
	TEM6185/LH	N/S Skip Arm – Early Type, Chain Driven

	TEM6185/RH	O/S Skip Arm – Early Type, Chain Driven
	TEM6190/LH	UK Locking Weld Claw – Left Hand (H0003928)
	TEM6190/RH	UK Locking Weld Claw – Right Hand (H0003931)
	TEM6230	Hyva Light Bracket – Left Hand (AE090965)
	TEM6231	Hyva Light Bracket - Right Hand (AE090964)
	TEM6308	Pin, main cylinder rod; Hyva 523405980 25mm diameter x 80mm long

	TEM6309	Hook Loader Cradle – 2656 (3mm thickness)
	TEM6310	Hook Loader Rear Roller Chem Spacer (AE090134)
	TEM6311	Hook Loader Rear Roller Bush/Flange Bearing (36207560)
	TEM6312	Skip Lower Extending Arm Mounting Axle Pin
	TEM6315	Bronze bush for main cylinder, base end. Hyva skip NG2012XL
	TEM6316	Bronze bush for main cylinder, rod end. Hyva skip NG2012XL, 12/14T

	TEM6320	XL-TA Circular Synthetic Wear Pad (P1003856)
	TEM7058	Hyva Wear Pad kit K45-055-02 (full kit for both sides)
	TEM7058/1	Hyva Skiploader Wear pad kit extending arm pads, retaining plates and fixings (NG2012XL & NG2018)
	TEM7058/2	Hyva Skiploader Wear Pad Kit for Extending Arm – Pads & Fixings Only (NG2012XL & NG2018)
	TEM7090	Large Skip Hinge – 250mm Long
	TEM7092/1	Strap Hinge – 160 x 40 x 6mm Approx

	TEM7092/2	Gudgeon Hinge Pin – 95 x 25 x 25mm Approx
	TEM7093	Rubber Bump Stop/Crossmember Buffer
	TEM7176	Pull-Over Cylinder (521700424)
	TEM7176/1	Top Hat Nylon Bushes – To Suit TEM7176/TEM7189
	TEM7176/2	Top Hat Nylon Bushes – TEM7176 Case End, 13mm Overall Length
	TEM7184	Clamping Plate – 75mm Wide x 165mm Long (523403300)

	TEM7185	Zinc-Plated Pin – 60mm Overall Length (523406460)
	TEM7186	BZP Pivot Pin – Approx. 98.34mm Long (523405625)
	TEM7187	Cylinder Rod Pivot Pin – 25mm Diameter x 70mm Long (523405970)
	TEM7188	Main Pivot Pin Locking Bar (523402622)
	TEM7189	Hydraulic Cylinder – 73mm O/D x 917mm Case Length (521700571)
	TEM7197/LH	Locking Cup – Left Hand

	TEM7197/RH	Locking Cup – Right Hand
	TEM7223	Hyva Hydraulic Tank
	TEM7224	Telescopic Outrigger Internal Section
	TEM7225	Hook Loader Pivot Axle (AE080033)
	TEM7226	Skip Lifting Plate – 20mm Thick (N0598041)
	TEM7235	Hyva Skip Loader Cradle – Sheet Roller

	TEM7237	Black nylon top hat bush 14mm long for fork end TEM7176 and TEM7189

Springs

	TES4040	Spring for Hyva roller (Same spring that goes inside TEM6054)
	TES4051 L/H	Skip Netting System Tension Spring (523415401)
	TES4052 R/H	Skip Netting System Tension Spring (523415400)

Valves

	TEV3032	5-Port Tip Hook Operating Valve – With Lever (34010100)

	TEV3035	Diverter valve (31020101)
	TEV3035/2	Titan Rear Lock Valve – With Plunger (31020100)
	TEV3047	In-Cab PTO Air Switch – Skip Wagon (520203824)
	TEV3071	Hyva Skip Oil Level Tank Gauge – 3" Sight Glass (08102129)
	TEV3081	Emergency Stop/Dump Valve Coil (NB000372)
	TEV3094	Control Valve Solenoid – 19W (523628724)

	TEV3100	Skip Loader Tip Hook Air Cylinder – Later Type (P1260279)

Specials

	TEX5018	1/8" BSP Straight Grease Nipple – To Suit TEM6167/1
	TEZ9044	Seal/Wiper Kit – Skip Handle Bracket/Spool
	TEZ9076	Pull-Over Cylinder (521700424)